

## **Breast Milk Fridge Temperature Monitoring and Action Planning**

**Breast Milk Fridge temperature** should be recording between **0 ° C and 4 ° C**. For fridge to function properly manufacturers instruction for circulating air and ambient room temperature should also be adhered to and regular maintenance must be carried out and recorded.

This should include:

- Regular cleaning and inspection of door and storage shelves
- Regular internal cleaning
- Daily cleaning of external door

Please note the temperature recorded is the air temperature within the fridge and will fluctuate when the fridge door is open and for the period after while the air temperature readjusts. If the fridge temperature is consistently recording out with the acceptable range this is a critical control point and must be actioned.

